



STANDARD COTTON BAG
width: 38cm
height: 41cm



FLAT BASE GUSSET BAG
width: 36cm
height: 41cm
gusset: 10cm



BASE AND SIDE GUSSET IRONED BAG
width: 35cm
height: 38cm
gusset: 9cm



BASE AND SIDE GUSSET BAG
width: 27cm
height: 38cm
gusset: 8cm



FLAT BASE GUSSET BAG
width: 43cm
height: 36cm
gusset: 12cm



SINGLE HANDLE BAG
width: 43cm
height: 36cm
gusset: 8cm



BASE AND SIDE GUSSET BAG
width: 40cm
height: 38cm
gusset: 10cm



STIFFENED BASE AND SIDE GUSSET BAG
width: 38cm
height: 40cm
gusset: 10cm



SINGLE HANDLE BAG
width: 46cm
height: 40cm
gusset: 12cm



ZIPPERED SPORTS BAG
width: 42cm
height: 32cm
gusset: 14cm



SINGLE HANDLE BAG
width: 38cm
height: 41cm



BEACH BAG
width: 60cm
height: 40cm
gusset: 16cm



FLAT BOTTOM COTTON BAG
width: 27cm
height: 30cm
gusset: 6cm



STIFFENED SEPARATELY BOTTOM AND SIDES COTTON BAG
width: 40cm
height: 38cm
gusset: 10cm



FLAT TWO-COLOUR COTTON BAG
width: 38cm
height: 41cm



FLAT BASE GUSSET BAG
width: 56cm
height: 38cm
gusset: 10cm



FLAT BASE GUSSET BAG
width: 43cm
height: 38cm
gusset: 8cm